
Trial series
T2005 3kW
Low Voltage Inverter Unit
Users Manual

Index

1. Introduction.....	3
1.1. Introduction	3
1.2. Suitable user	3
1.3. Caution	3
1.4. Warning	4
2. Inverter overview.....	7
2.1. Feature	7
2.2. Inverter block diagram	7
2.3. T2005 specifications	8
3. Precautions for each circuits blocks.....	9
3.1. Choice of the current detection circuits	9
3.2. The filter circuits for the current detection	11
3.3. Over current detection circuits	12
3.4. Voltage detection circuits.....	13
3.5. How to choose CPU voltage	13
3.6. Connection information with CPU board.....	14
3.7. DC Link voltage below 22V or Using separate power supply between main and control	15
4. External connection for T2005	16
4.1. FAN power input (AC100V or AC200V)	16
4.2. Inverter AC output.....	16
4.3. Inverter DC input.....	17
5. Temperature raise value data for T2005.....	18
5.1. Temperature raise value data.....	18
6. Ordering information	19
6.1. Order number list.....	19

1. Introduction

1.1. Introduction

This users' manual is for T2005 low voltage inverter training kit. These inverters are designed for PMSM motor and induction motor. When you use this inverter, please check your motor specifications like sensor, power, voltage range, current range and so on.

1.2. Suitable user

This inverter is suitable for research or development stage.

1.3. Caution

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Desk Top Laboratories Inc products listed herein, please confirm the latest product information with a Desk Top Laboratories Inc. Also, please pay regular and careful attention to additional and different information to be disclosed by Desk Top Laboratories Inc such as that disclosed through our website.
2. Desk Top Laboratories Inc does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of Desk Top Laboratories Inc products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Desk Top Laboratories Inc or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Desk Top Laboratories Inc product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Desk Top Laboratories Inc assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Desk Top Laboratories Inc products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Desk Top Laboratories Inc products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Desk Top Laboratories Inc has used reasonable care in preparing the information included in this document, but Desk Top Laboratories Inc does not warrant that such information is error free. Desk Top Laboratories Inc assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Desk Top Laboratories Inc products are classified to the experimental use. Especially, you may

not use any Desk Top Laboratories Inc product for any application for Transportation equipment (automobiles, trains, ships, etc.), traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support; Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support.

8. You should use the Desk Top Laboratories Inc products described in this document within the range specified by Desk Top Laboratories Inc, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Desk Top Laboratories Inc shall have no liability for malfunctions or damages arising out of the use of Desk Top Laboratories Inc products beyond such specified ranges.

9. Although Desk Top Laboratories Inc endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Desk Top Laboratories Inc products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Desk Top Laboratories Inc product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.

10. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Desk Top Laboratories Inc.

1.4. Warning



- There is a risk of fire.

If you find inverter firing, Fuming, abnormal sounding, or other abnormal conditions, stop the inverter immediately. After you stop the inverter, you should disconnect all wiring connected to the inverter.



- There is a risk of electrical shock.

There is a high voltage parts inside the inverter. Do not touch directly on working or after you stopped the inverter, while there is a charge in the capacitor. If you don't keep this warning, by electric shock, there is a risk of serious injury or death.



- There is a risk of blindness.

This inverter has an enclosure. If the inverter ruptured while opening the lid of the enclosure, there is a possibility the liquid contained in the internal capacitor, such as

damaged parts enters the eyes, and it would make you blindness. Please do not open the lid of the enclosure after stopped the inverter immediately, even during the operation. If you open the lid, please be sure to wear goggles for protection such as in the photo below.



Caution

- There is a risk of burns

While driving or after stopped, this inverter gets hot such as more than 100 degree. If you touch the inverter, please pay attention to the temperature.



Caution

- Please do not block the air vents of the enclosure. (only for T2000B)

In this inverter there is a vent for cooling the inside. If you block the air vent, cooling capacity is reduced. And it may cause the inverter damage or fire.



Caution

- Please drive the FAN while driving the inverter. (only for T2000B)

In this inverter there is a FAN to cooling the inverter. If you do not drive the FAN while driving the inverter, the temperature of the inverter will rise, it may cause the inverter damage or fire.



Caution

- If you want to create a software, please create the protection routine first, such as over-current protection, over-heat protection and so on.

In this inverter, there is no mechanism to protect the inverter hardware alone. Please make the protection software first, or you may break the inverter.



Caution

- Do not drive the inverter when the ambient is very high or very high humidity.

This inverter is designed for experimental use. So this inverter won't work under below conditions. Do not use under the environment that is out of the operation environment of this manual.

- Environment where there is vibration and shock.
- Environment where there is saprophagous gas, combustible gas, humidity over 90%
- Very High or very low temperature environment



Caution

- This product handling high voltage. Please use a person who is aware of the danger of high voltage.

The wiring materials are enclosed in this inverter for reference. But they do not necessarily mean that they are appropriate for your application. Please use it before check the applications.



Caution

- Rating of this product is measured under certain conditions.

Maximum power capacity would be affected by input voltage output voltage, output current, load conditions, operations conditions and ambient temperature. To prevent the inverter broken, please watch the temperature, current, voltage, and external sensors for to protect inverter.

2.3. T2005 specifications

Item	Specifications	Note
Operation temperature	0°C~35°C	
Operation humidity	Below 90% (No dew condensation)	
Size	280 x350 x 195 mm	
Weight	3.6kg	
Input voltage range	DC12V~DC48V	
Maximum output power	3kW / 3.6kVA @ DC48Vinput	
Rated output current	AC70Arms @ AC30V output	@ switching frequency 15kHz
Switching frequency	2kHz~20kHz	This value is for your information
Deadtime	2.0us	This value is for you r information.
Current detection	3 shunt	User can modify for 1 shunt current detection
Shunt register	1mΩ	
Switching device	IRFS7730-7PPBF	Infineon
Control power supply	Generated from DC link	Non-isolated
DC link – control circuit isolation	Non-isolated	
Cooling	Forced air cooling with AC FAN	
PFC controller	No	
Temperature sensor	No	
ICS	No	

*Caution: Each maximum value, the rated value, may be changed by the type of load, input voltage, ambient environment, such as by air cooling conditions. Desk top laboratories Inc does not guarantee the condition of all the rated and maximum values of these specifications. Please install the protection way by the customer, depending experimental environment and the load environment.

3. Precautions for each circuits blocks

3.1. Choice of the current detection circuits


There are two outputs of the current detection circuits of this inverter. Two outputs are selected by JP7, JP8, JP9. Please choose JP setting according to your CPU setting.

T2005 @AVcc = 5V

JP	1-2 Short, 2-3 Open		1-2 Open, 2-3 Short	
	Outputs	Equations	Outputs	Equations
JP3	Iu OPAMP output	$V_{out} = (10 * R * I_{in} + AV_{cc}) / 2$ $R = 1m\Omega$ $I_{in} = 500A \rightarrow V_{out} = 5V$ $I_{in} = 0A \rightarrow V_{out} = 2.5V$ $I_{in} = -500A \rightarrow V_{out} = 0V$	Iu direct output	$V_{out} = (9 * R * I_{in} + AV_{cc}) / 2$ $R = 1m\Omega$ At internalOPAGain=5 $I_{in} = 555A \rightarrow V_{out} = 5V$ $I_{in} = 0A \rightarrow V_{out} = 2.5V$ $I_{in} = -555A \rightarrow V_{out} = 0V$
JP11	Iv OPAMP output		Iv direct output	
JP12	Iw OPAMP output		Iw direct output	


T2005 @AVcc = 3.3V

JP	1-2 Short, 2-3 Open		1-2 Open, 2-3 Short	
	Outputs	Equations	Outputs	Equations
JP3	Iu OPAMP output	$V_{out} = (10 * R * I_{in} + AV_{cc}) / 2$ $R = 1m\Omega$ $I_{in} = 333A \rightarrow V_{out} = 3.3V$ $I_{in} = 0A \rightarrow V_{out} = 1.65V$ $I_{in} = -333A \rightarrow V_{out} = 0V$	Iu direct output	$V_{out} = (9 * R * I_{in} + AV_{cc}) / 2$ $R = 1m\Omega$ At internalOPAGain=5 $I_{in} = 366A \rightarrow V_{out} = 3.3V$ $I_{in} = 0A \rightarrow V_{out} = 1.65V$ $I_{in} = -366A \rightarrow V_{out} = 0V$
JP11	Iv OPAMP output		Iv direct output	
JP12	Iw OPAMP output		Iw direct output	




3.2. The filter circuits for the current detection

The filter parameters for the current detection circuits need be changed by the application, noise environment, switching frequency, control algorithm and so on. As shown below, this inverter provides the pattern of the filter capacitor.



3.3. Over current detection circuits

The over current detection circuits of this inverter use the comparators. The outputs of the comparators are connected to the /INT pin of CPU. So user need to install the gate-block routine to your application.



3.4. Voltage detection circuits


This inverter has four voltage detection circuits.

$$AV_{cc} = @5V$$

Voltage	equations
DC link	$V_{out} = \frac{0.47k}{10k + 0.47k} \times V_{in}$
U phase	
V phase	
W phase	$V_{in}=111V \rightarrow V_{out}=5V$ $V_{in}=0V \rightarrow V_{out}=0V$

$$AV_{cc} = @3.3V$$

Voltage	equations
DC link	$V_{out} = \frac{0.47k}{10k + 0.47k} \times V_{in}$
U phase	
V phase	
W phase	Vin=73.5V -> Vout=3.3V Vin=0V ->Vout=0V



3.5. How to choose CPU voltage

This inverter board automatically supplies the proper CPU voltage. You don't worry about how to choose CPU voltage.

3.6. Connection information with CPU board

CN-A Digital	Direction	STD Inverter	T5201 RX62T 100pin *1	T5205 RX23T	T5101 RL78/G14 64pin	T5301 RX111 64pin	T5102 RL78/F14 80pin	T5103 RL78/G1F
1	To INV	–	PA2	P00	P52	P32	P44	P141
2	To INV	–	PA3	P01	P53	PB0	P47	P140
3	To INV	PFC_G1	PD0	P31	P54	PA1	P41	P04
4	To INV	VRL	PB3	PB4	P55	PA0	P42	P55
5	To CPU	/FO	P70	P70	P137	PB5	P137	P137
6	To CPU	–						
7	To INV	WN	P76	P76	P10	P55	P30	P10
8	To INV	VN	P75	P75	P11	PB1	P16	P11
9	To INV	UN	P74	P74	P14	PB6	P120	P14
10	To INV	WP	P73	P73	P12	P54	P17	P12
11	To INV	VP	P72	P72	P13	PB3	P15	P13
12	To INV	UP	P71	P71	P15	PB7	P125	P15
13	To CPU		P91	P91	P05	P35	P46	P05
14	To CPU		P92	P92	P06	P31	P45	P06
15	To CPU	5V	5V	5V	5V	5V	5V	5V
16	To CPU	5V	5V	5V	5V	5V	5V	5V
17	To CPU	GND	GND	GND	GND	GND	GND	GND
18	To CPU	GND	GND	GND	GND	GND	GND	GND
19	To CPU	3.3V	3.3V	3.3V	3.3V	3.3V	3.3V	3.3V
20	To CPU	3.3V	3.3V	3.3V	3.3V	3.3V	3.3V	3.3V

CN-B Analog	Direction	STD Inverter	T5201 RX62T 100pin *1	T5105 RX23T	T5101 RL78/G14 64pin	T5301 RX111 64pin	T5102 RL78/F14 80pin	T5103 RL78/G1F 64pin
1	To INV	AVCC	5V	5V	5V	3.3V	5V	5V
2	To INV	AVCC	5V	5V	5V	3.3V	5V	5V
3	To CPU	–						
4	To CPU	–						
5	To CPU	IU	ANI 000	AN000	ANI 0	ANI 0	ANI 2	ANI2
6	To CPU	IV	ANI 001	AN001		ANI 1	ANI 4	-
7	To CPU	IW	ANI 002	AN002	ANI 1	ANI 2	ANI 3	ANI3
8	To CPU	VPN	ANI 003	AN003	ANI 2	ANI 3	ANI 8	ANI4
9	To CPU	TEMP (Vot)	ANI 0	AN007	ANI 7	ANI 4	ANI 10	ANI7
10	To CPU	VU	ANI 101	AN004	ANI 3	ANI 6	ANI 5	ANI16
11	To CPU	VV	ANI 102	AN005	ANI 4	ANI 8	ANI 6	ANI0
12	To CPU	VW	ANI 103	AN006	ANI 5	ANI 11	ANI 7	ANI1
13	To CPU	(VAC)	ANI 1	AN016	r ANI 16	ANI 12	ANI 9	ANI5
14	To CPU	(IPFC)	ANI 100	(AN017)	r ANI 17	ANI 13	ANI 13	ANI18
15	To CPU	(VR1)	ANI 2	AN017	ANI 6	ANI 14	ANI 11	ANI6
16	To CPU	(RSV)	ANI 3	-	ANI 19	ANI 15	ANI 12	ANI17 (Yin)
17	To INV	VCCIO	5V	5V	5V	3.3V	5V	5V
18	To INV	VCCIO	5V	5V	5V	3.3V	5V	5V
19	To CPU	GND	GND	GND	GND	GND	GND	GND
20	To CPU	GND	GND	GND	GND	GND	GND	GND

3.7. DC Link voltage below 22V or Using separate power supply between main and control

The control power is generated from the DC link voltage. But if the DC link voltage is below 22V, it cannot generate the control voltage. If you want to use below 22V for DC link voltage, you need to separate DC link and the control power source.

A) DC link voltage is below 22V. or to separate DC link and the control power source.


- 1) Remove the short socket on JP85
- 2) Connect power supply. +15V is for CN1 1pin. And GND is for CN1 3pin.

B) The case of to generate control power from the DC link. (Default)

- 1) Install the short socket for JP85 (Default)
- 2) Remove the connection for CN1.


4. External connection for T2005

4.1. FAN power input (AC100V or AC200V)




Connect AC100 / AC200V depending on the model

4.2. Inverter AC output



4.3. Inverter DC input



DC inputs — DC input +

5. Temperature raise value data for T2005

5.1. Temperature raise value data

This is example of the temperature raise value data of this inverter.

If you stop the FAN when you driving the inverter, the inverter may get very high temperature and would be broken. Please make sure to run FAN, when you drive the inverter.

Condition:


T2005 inverter + RX62T 100pin CPU card

Ambient 20°C

Load 3 phase LR load

FAN ON

Time [min]	Output Current W phase	W phase MOSFET	Capacitor U-V	W phase Gate Driver	W phase Gate driver
0min	100Apeak	20	20	20	20
2	100Apeak	50	32	38	
4	100Apeak	54	38	42	50
8	100Apeak	57	42	47	53
13	100Apeak	58	42	47	54
18	100Apeak	59	43	48	55



6. Ordering information

6.1. Order number list

This product has no options

型番	
T2005-V100	AC FAN voltage AC85V~AC110V
T2005-V200	AC FAN voltage AC165V~AC230V
T2005-VD48	DC FAN voltage 48V (custom version)
T2005-VD24	DC FAN voltage 24V (custom version)

Trial series T2005 Low Voltage Inverter Unit Users Manual

Issue date: 13-Sep-2017 Ver.1.01 EN

Issue: Desk Top Laboratories Inc.
101, 35-7, MATSUGI, HACHIOUJI-SHI, TOKYO, Japan, 192-0362
